

# THE GEEK SHACK

## THE BUDGE 1.0 WIRELESS HORN

Fitting instructions.

TX.

- First fit the battery + side out into the battery hold by sliding the top in first.
- Then put the bottom of the battery in until it clicks into place.



- Now with the horn push removed from the steering wheel line the switch with the largest of the three holes in the horn push.
- Make sure the lever of the switch is tucked under the edge of the hole.



- Clip the outer edge of the TX carrier over the horn push spring.
- Push the TX carrier on to the horn push until it sits flat on the horn push.



- Press the horn and make sure you can hear the click of the switch, if you can't, remove the TX carrier from the horn push and bend the switch lever up by holding the hinge end with long nose pliers and bending the other end up with your finger. Be careful not to put any force on the hinge of the switch. Refit the TX carrier to the horn push.
- Now get the steering wheel and line the largest void with the large pod on the underside of the TX carrier.



- Slide the TX carrier and horn push into the steering wheel, once in place make sure you can still hear the click of the switch.
- Once this is complete you can wire in the RX, instructions are on the website.

Please make sure the RX is within 1-1.5m of the TX and test it is getting a signal before you complete installation.

#### NOTE.

If you need to remove the horn push and TX carrier from the steering wheel please take care. The horn push will come off leaving the TX carrier in the steering wheel, this must be removed straight as if you pull it out at an angle it will jam and cause damage to the carrier.