



Stealth USB charger fitting instructions.



First locate the speaker mount hole under your dash as shown here.



Place the screw through the hole and locate in the bottom of the USB Charger.



Once the screw is located and loose make the USB charger is in the dash grills and pushed home before tightening the screw. Holding them push in whiles tightening.

Connect the wires to a 12v 5- amp fused feed, red- positive and black- earth.