

# THE GEEK SHACK

## Stealth USB charger fitting instructions.



- You will need to remove the ashtray and ashtray outer case.



- With the drill bit provided, measure 70mm from the back of the ashtray case and drill as close to the edge as you can.



- Now push the USB unit into the ashtray, lifting the spring to give yourself more space. It maybe necessary to pull the side open a little to push the unit in.



- push the back of the unit down and it should sit just under the lip on the side of the ashtray.



- Slide the unit forward until the hole lines up with the hole on the ashtrays tab.



- Screw in the machine screw provided and make sure the cables are tucked in the back corners recess.



- If you have a small file it is a good idea to clean up the hole in the ashtray case. Now put the ashtray case back in the beetle before continuing and feed the cables into the hole.



- Now with the wires over the rear corner cut out of the ashtray, push the ashtray into the case. There will be a little resistance (not a lot so stop if there is.) You will feel the ashtray pop past the wires, and they will become loose.

- Now push the ashtray all the way home and pull the wires out as far as you can. Open the ashtray to its locked in limit, allowing the wire to go back though the hole. Now pinch the wires with your fingers and move the ashtray in and out to make sure the wires are moving freely. Once you are happy with this you can insert the gromet and recheck the wires.

Connect the wires to a 12v 5-amp fused feed (inline fuse provided), red-positive and black-earth.