

Sun visor shelves.

- Installation guide -

Parts -

2 x Metal shelves

2 x C-trims

2 x Non-slip mats

4 x Plastic dome spacers

2 x Flat washers

2 x Pan head M4 machine screws

2 x Countersunk No' 7 screws

4 x Pan head No'7 screws

With your sun visor uninstalled, start by installing it with the top hole using one of the Countersunk No' 7 screws. Making sure the other two holes are lined up.



Remove this screw from your fresh air vent cover.



With your Flat washer and Pan head M4 machine screw, attached the tab of the metal shelf to the screw hole on the fresh air vent cover loosely.



Now install the two of the Pan head No'7 screws through the holes on the sun visor bracket side on the metal shelf along with two of the Plastic dome spacers.



Locate them into the sun visor and screw them in.



Now tighten the Pan head M4 machine screw on the fresh air vent cover. Add your C-trim to the top edge of the shelf and your non-slip mat.

You're all done.

Repeat for the other side.